

INSTALLATION INSTRUCTIONS
FOR INDUCTION KIT SSHP
GOLF II GTi DIGIFANT

Please read instructions before starting work

Tools Required

- | | |
|---------------------------|---------------------|
| 1. M10 Socket and spanner | 2. Flat screwdriver |
|---------------------------|---------------------|

Kit Contents

- | | |
|--------------------|------------------------|
| 1. Power Cone. | 6. M6 Washers x 4. |
| 2. M8 Washers x 4. | 7. M8 Nylock nuts x 2. |
| 3. M6 nuts x 4. | 8. Hose clip. |
| 4. Gasket. | 9. M8 Bolts x 2 |
| 5. Main bracket | 10. Hose cap |

Removing Standard Air Filter Housing

- Step 1. Disconnect electrical air sensor
- Step 2. Loosen hose clip
- Step 3. Disconnect air sensor hose
- Step 4. Unclip canister lid and remove lid and management system
- Step 5. Disconnect management system from lid.
- Step 6. Unclip 2 x 'O' rings and remove canister bottom from inner wing.

Installing the Power Cone

- Step 1. Fit bracket to studs using nuts supplied
- Step 2. Connect filters to management system, be sure to fit cork gasket.
- Step 3. Trace air sensor pipe back and cap off with plug supplied.
- Step 4. Insert Filter/system into hose and secure with hose clip
- Step 5. Bolt through bracket into system with bolts supplied.
- Step 6. Re-connect electrical sensor

